

WELCOME

Important Information About your Big Bear Foam Machine

Congratulations on your purchase of this SnowMasters foam machine. With your foam machine you will dazzle and entertain audiences in large or small venues. Your Big Bear Foam Machine is manufactured with many features, but at the same time it is very easy to use.

The Big Bear is a recreational foam generator used for creating an entertaining environment for parties, nightclubs, and fun special effects. Its sleek design makes it a popular appliance for years and years of foam making. The Big Bear will produce large quantities of foam in a short period of time (10-20 minutes), so there is fun for all as soon as the Big Bear is activated.

IMPORTANT PRODUCT AND SAFETY INFORMATION

Failure to follow these instructions can cause serious bodily injury or property damage.

CAUTION: YOU MUST READ THE FOLLOWING BEFORE OPERATING THE Big Bear Foam Machine.



The Big Bear is an electric product and not a toy. Adult supervision is continuously necessary to avoid the risk of electric shock or personal injury. **It should not be operated or placed where small children can reach it.** Always keep fingers away from the fan guard and never remove the guard or the electronic enclosure cover. Children should also always stay away from the solution container at all times to minimize the risk of shock or drowning.



The Big Bear generates a layer of foam on every surface that obscures ground vision and can cause slipping. Always prepare your foaming area using a flat surface free of obstructions, such as steps, standing water, cables, ledges, electronic equipment, rocks, toys, and sharp objects before generating foam.

Never place the pump in water or remove the pump from the water while the Big Bear is plugged into an electronic socket. **Always use a plastic container to hold solution.**

Do not run the Big Bear while the solution container has a water or solution level lower than 1/8". Never use water with a temperature greater than 104 Degrees F. Never use any ingredient in your solution container other than water and/or your Snow Master's foam solution. If you do not follow these directions, the pump and Big Bear can be damaged.

Always operate the Big Bear on a dry, level surface. The cables and hose should be routed so that pedestrian traffic cannot trip over the cable or hose.

Never leave the Big Bear unattended while operating. Do not operate it in the rain or in standing water. Do not place the Big Bear within 10 ft (3 meters) of a swimming pool, steps, or a ledge without a guardrail.

Use Caution when adjusting the vertical aim of the Big Bear nozzle, since it may rotate freely when unlocked and contact (injuring) someone underneath the cone.

Always use an outlet with an earth grounding receptacle and a Ground Fault Circuit Interrupt (GFCI).

Never use this product for any activity other than for what it is intended.

Big Bear Features and Specifications

Features

- Hanging points on top of machine
- Low consumption of water and foam concentrat
- Lifetime warranty
- Long lasting dry foam
- Fast type connector for water inlet
- Hook up standard garden hose to tap water
- 24-Hour Technical Service
- GFI Protection

Specifications

Voltage:	110 60 Hz or 220 60 Hz
Fuse:	20 Amps
Size:	22.5" Wide, 22" Long and 22" Tall
Weight:	50 lbs
Materials:	Predominately Plastic
Foam GenerationRate:	500 cubic square feet per minute (approximate)
Cable Length	20 feet
Hose Length:	10 feet



Foam Solution Mixture

Solution Mixture:



Snow Masters are constantly inventing and reformulating solutions in order to improve the foam from the Big Bear. Please contact Snow Masters at 256-229-5551 for more information on new foams. In order to prevent operation problems, always use a Snow Masters approved foam solution. Failure to use approved Snow Masters solution will automatically void the lifetime warranty.

Always mix and store the Solutions in a plastic container.

FG-HDF Solution. The ratio for this foam solution is 50 units of water to 1 unit of solution. See the chart below for some examples of common water/solution ratios for the FG-HDF Solution only.

Minimum Container Size	Water	FG-HDF Solution		
		Gallons	Quarts	Ounces
12 gallons	10 gallons	.2	.8	26
26 gallons	25 gallons	.5	2	64
32 gallons	30 gallons	.6	2.4	77
42 gallons	40 gallons	.8	3.2	102
52 gallons	50 gallons	1	4	128

Stir the solution in the container before operating the Big Bear.



General Operating Instructions


Operating Instructions:

The Big Bear has some simple instructions that must be followed carefully in order to create rich foam, ensure the safety of the operators/participants, and to protect the equipment from damage. PLEASE FOLLOW THESE INSTRUCTIONS CAREFULLY.

The Big Bear uses a sump pump and a premixed solution to ensure that the solution flow rate is ideal in the creation of foam. The two electrically operated pieces of equipment in the Big Bear are the Sump Pump (110V or 220V) and the Blower-fan (110V or 220V), and are controlled by a GFI.

1) Prepare the area you intend to fill with foam. Always prepare your foaming area; making sure it is a surface free of obstructions such as steps, standing water, cables, ledges, electronic equipment, rocks, toys and sharp objects before generating foam. Note that if the area surface is linoleum, it will be much more slippery than an outdoor carpet, concrete or lawn. Always warn participants that the foam can make the floor slippery, which is part of the fun.

2) Locate the Big Bear exactly in the middle of the area you intend to fill with foam. Place Big Bear in the desired direction. Make sure the Big Bear is resting on a surface that is level and dry. It should never be located within 10 ft of a swimming pool, steps or ledge without a guardrail.



3) Prepare the foam solution in a plastic container (per the "Solution Mixture" section) and locate it within 15 ft of the Big Bear. The container should always be plastic. Lower the Sump Pump into the container. Plug in the Sump Pump Cord to the electric connector on the Big Bear's electronic GFI power supply. **The Big Bear should never be plugged into the electrical outlet when lowering or raising the Sump Pump from the solution container.** The Sump Pump should never be run with less than an 1/8" of solution in the solution container or you will damage the pump.

4) After clearing people away from the nozzle end of the Big Bear, plug the electric cord into the 110V or 220V outlet. Press down on the switch marked "ON" to turn on the Big Bear. In less than 10 seconds, foam should flow out of the Big Bear nozzle. If foam is not created after 1 minute, turn off and unplug the Big Bear. Review the Q/A Problems section in this

General Maintenance and Cleaning

Operating Instructions:

When you have created a desired amount of foam or emptied the container, turn off the Big Bear by pressing on the lower part of the "ON" switch. Always unplug the Big Bear when you are not supervising its operation.

5) After running the Big Bear for 30 seconds, use the adjust valve below the Big Bear. This will allow you to tweak the richness of the foam (wetter or dryer). The foam should pour out from the front of the Big Bear and immediately drop toward the ground. Have Fun Making Foam!

General Maintenance

Fuse Replacement:

The Big Bear uses a reset able GFI protected fuse box. If the GFI is tripped, check for the cause, then reset. If it continues contact Snow Masters customer service at 1-256-229-5551.

Hose Replacement:

Upon damaging the hose, replace it with a standard 20-foot long garden hose. A longer hose may affect foam output.

Electrical Wire Damage:

Snow Masters will repair all wire damage per the lifetime warranty.

General Repair:

The Snow Masters Big Bear has a lifetime warranty **and should never require you to remove the electrical panel or fan guard (extreme danger).**

Please contact Snow Masters if you have questions on its operation.

Cleaning Simplified

In order to clean the Big Bear, fill another plastic container with water and insert the Sump Pump (the Big Bear, or Pump unplugged) as before. Run the Big Bear for 3-5 minutes. After a minute or so, it is normal for water to run out from the back end of the Big Bear. Use a mild cleanser on the Outside of the Big Bear except on the FAN housing, Plastic Container and Tubing/Valve/Switches/Connectors/Hose/Wire.

Types of Trouble and Their Solutions

Symptoms and Cause and/or Corrective Actions

1

If the Big Bear does not generate foam, review the following checklist.

- a)** Is the Fan Operating? (Air is shooting out nozzle of Big Bear.)

Yes: Move on to (b)

No: Check the electric plug interface to the outlet connection. Check the “Blower” Switch-press it up and down. Unplug the outlet plug before checking the fuse (see fuse changing instructions above). If it still does not operate, call Foam Masters Technical Service.

- b)** Is the Sump Pump Operating? Is there water coming out of the Big Bear when you turn it on?

Yes: Go to (c)

No: Make sure the pump is submerged in solution. Check that the electrical connection between the pump and the Big Bear electrical box connector is locked. Make sure the hose is hooked up between the pump and the valve connection on the Big Bear. If it still does not operate, call Foam Masters Technical Service.

- c)** Adjust the hand valve below the Big Bear to a number of positions to see if it helps generate a dryer or wetter foam. Create another batch of solution and double check that you match one of the “solution mixtures” noted above (for the correct solution type). Retest the Big Bear with the new solution batch. If it still does not generate foam, call Foam Masters Technical Service.

- d)** Is the mix of foam to water correct? Try mixing one more gallon of HDF to the reservoir with water.

Warning: Some municipal city water sources have harsh minerals that may cause bad production of foam. In other cases, bad production of foam may be caused by the facility using a water softener. The water softener acts like a de-foamer and does not produce good foam.

Technical Service

Snow Masters 24 hr Technical Service line at:

1-256-229-5551 or email service@snowmasters.com

www.SnowMasters.com

Sales - 1-256-229-5551



11054 County Road 71 Lexington,
AL 35648

www.SnowMasters.com

AUSTRALIA • NASHVILLE
LOS ANGELES • FORT LAUDERDALE

Sales: 1-256-229-5551
Fax: 1-256-229-5552

24 Hour Tech Support
1-256-229-5551

The Big Bear Foam Machine

The
Ultimate
Foam
Generator



SNOW
M · A · S · T · E · R · S
SPECIAL EFFECTS
Making the memorable magical.

www.SnowMasters.com